



Mod Specification

Size: 27MM * 93MM Battery Type: 18650,20700, 21700 Mod material: Aluminium Alloy+304SS Support Min. Resistance: 0.1Ω Output Voltage: 3.5V Net Weight: 61G

Atomizer Specification

Size: 25MM * 39.5MM(With Drip Tip) Material: Aluminium Alloy + 304SS Capacity: 3ML Coil Resistance:0.16Ω/0.2Ω Net Weight: 76G Top Airflow Control, Avoiding Leak and Condensation Top Sliding Fill System Adjustable Airflow System 810 Drip Tip

Protection Function

Low Voltage Protection
Over-Charging Protection
Over-Heating Protection
No-Load Protection
Short-Circuit Protection
Over-Time Protection
Anti- Reverse Connection Protection

Matters need attention

- 1.Please refill the cartridge in-time to avoid dry-burning.
- 2.Do not keep pressing the ignition key to keep the device working under abnormal circumstances.
- 3.Keep it in cool place.
- Do not use it before refilling juice to avoid drv-burning.

Intelligence Indicator Light

1.Turn on/off, press the button 5 times quickly. Power on, the indicator rainbow light flash 2 times: Power off, the indicator rainbow light flash 5 times 2. When the device start working, the indicator light will shine, while it stop vaping, then the light lights off. If the battery voltage is between 3.5V-4.2V. the light will be green; If the battery voltage is between 3.3V-3.5V, the light will be vellow; If the battery voltage is between 3.2V-3.3V, the light will be red and flash 3 times to show low power. Then the device will stop work, please charge it in time. 3. When atomizer contacts with the mod, the indicator light flash 1 time.

4.If it is short-circuit, the indicator light will flash 2 times, and light as red, green, and blue change rapidly. Meanwhile the product stopping work. 5.When charging, the red light shinning 2s then light-off, after 1s, works again like this. Once it is be charged fully, the light becomes green and lasts 60 second, then light off.

6.After vaping 8s continuously, the device will stop work meanwhile the power light will flash 2 times 7.If overheating protection is triggered, the red light flashes 10 times and stop smoking at the same time.

8. Without atomizer, the red light flashes 5 times and stop making output.

Atomizer filling illustration

1. Push forward the slide refilling top cap.



2.After refilling the e-juice, please let the cartridge stand in 5 minutes to make sure that cotton be fully soaked before use.



3. Recover the sliding part after refilling.



2.Make sure the two positive poles of 3.Please put the battery sleeve if use **Coil Head Installation Battery Installation illustration** both battery and mod be connected, 18650 battery. then tighten the negative terminal. 1.Unscrew the base from the atomizer. 1.Unscrew the negative terminal. 2. Tighten the new coil head on the base. 3. Tighten the base and atomizer.